

# ERA

## 803-12 Sash Window Bolt Fitting Instructions

### Sash Window Bolt

To fit a Sash Window Bolt you will require:

- Bradawl (or drill with 2.5mm drill bit)
- Posidriv screwdriver
- Flat blade screwdriver
- Pencil

If Fitting to hardwood drill 2.5mm pilot holes

- Close window and select position of lock
- Locate lock mechanism on lower sash ensuring base of lock mechanism is flush with edge of frame. Mark screw holes and screw lock to frame
- Position receiving plate on upper sash ensuring bolt passes centrally through receiving plate. Set receiving plate slightly back from edge of frame to ensure window can pass. Mark screw holes and secure receiving plate with security screws supplied

### Additional Information

**Operation** - Push bolt to lock. Turn key anti clockwise to open

**Security Tips** - We recommend fitting 2 sash bolts. These should be positioned 150mm in from each side of the window

