



830-12 PVCu Snaplock Fitting Instructions

Installing a PVCu Snaplock (keyless)

To fit a PVCu Snaplock you will require the following tools:

- Drill
- 1.5mm drill bit
- Posidriv screwdriver

(Please ensure screws enclosed are suitable for applicataion prior to use).

- A** From the inside of your house, close the window and select the correct position for the PVCu Snaplock on the outward opening frame:
- ◀ Position if fitting with a single lock
 - ◀ Position if fitting with two locks
- B** Drill pilot holes using the PVCu Snaplock as a template. Drill through the frame and the inside wall of the frame. If you encounter a reinforced steel or aluminium section, drill through that section carefully as to not touch the glass. Fix the PVCu Snaplock to the frame using suitable screws to ensure a tight fit. Once done, push the plastic screw cover over the screw head holes with a gentle push-fit.
- C** To ensure a tight fit of the finger to the frame when in the locked position, select a pad from those provided and press the pad into the hole provided in the finger. Take care that the fit is not so tight as to mark the PVCu frame.

Additional Information

Operation - Swing the finger over the fixed frame to stop the window opening. To free the window open, swing the finger back over the fixed base.

Maintenance - Use a moist cloth only to clean all types of finish, household abrasives or solvents may affect the surface finish - lubrication may occasionally be required.

