



784-32 160° Door Viewer Fitting Instructions

Installing a 160° Door Viewer (Glass Lens)

This product is suitable for doors between 35mm and 54mm in thickness.

To fit a 160° Door Viewer you will require the following tools:

- Drill
- 14mm drill bits
- Flat blade screwdriver
- Pencil

- Select position at eye level in centre of door, mark position and drill a 14mm hole through door.
- Insert lens through door from outside.
- Slide lens cover over adjustment barrel. Insert adjustment barrel from inside of door and while holding the lens, screw adjustment barrel until tight. Use screwdriver if necessary.

Additional Information

Security Tips - We recommended you always view visitors through the door viewer before opening the door.

Safety Tips - For additional safety we recommend the use of an ERA 791 Door Chain or ERA 700 Concealed Door Chain.

Maintenance - Use a moist cloth only, household abrasives or solvents may affect the surface finish.

