



## 786-32 120° Door Viewer Fitting Instructions

### Installing a 120° Door Viewer (Glass Lens)

This product is suitable for doors between 35mm and 54mm in thickness.

To fit a 120° Door Viewer you will require the following tools:

- Drill
- 14mm drill bits
- Flat blade screwdriver
- Pencil

- Select position at eye level in centre of door, mark position and drill a 14mm hole through door.
- Insert lens through door from outside.
- Slide lens cover over adjustment barrel. Insert adjustment barrel from inside of door and while holding the lens, screw adjustment barrel until tight. Use screwdriver if necessary.

### Additional Information

**Security Tips** - We recommended you always view visitors through the door viewer before opening the door.

**Safety Tips** - For additional safety we recommend the use of an ERA 791 Door Chain or ERA 700 Concealed Door Chain.

**Maintenance** - Use a moist cloth only, household abrasives or solvents may affect the surface finish.

