



1880-32 Tubular Latch Fitting Instructions

Installing a Tubular Latch

To fit a Tubular Latch you will require the following tools:

- Drill
- 10mm and 22mm drillbits
- Screwdriver
- Pencil
- Chisel

Note: Suitable for doors between 35mm to 45mm in thickness.

- Select the position of the Tubular Latch on the door.
- Open door, mark the hole positions in the centre of the door edge. Drill a 22mm hole to a depth of 65mm for a 64mm latch and 80mm for a 76mm latch (to accept latch case), ensuring you keep the drill straight and level at all times. Place tubular latch in hole. Using a pencil draw around the forend of the latch. Remove latch and chisel out so that the latch face is flush with the door edge.
- Close door gently against the door frame. Mark the top and bottom positions of the latch plate on the door frame. Position striker plate within markings and using a pencil draw around the striking plate and mark location of receiving hole. Rebate striker (if necessary) using chisel. Remove timber from the frame using a chisel to a suitable depth to accept the latch bolt. Fix striking plate in position required, then check operation

Additional Information

Maintenance - Use a moist cloth only - lubrication may occasionally be required.

