

## Spire Door Knocker Fitting Instructions

To fit this Knocker you will require the following tools:

- Pencil
- Drill
- Tape Measure
- Drill bit (2mm)
- Screwdriver

### Installing a Spire Door Knocker

- 1 The Spire knocker is face fixed to the door. This ensures ease of installation.
- 2 Please use a tape measure / rule and square to correctly position the knocker on the door, please check the knocker is in the desired location before marking any holes **A**.
- 3 With the knocker fixing plate correctly located, mark the 4 fixing holes with a pencil **B**. Drill the pilot holes.

**NB:** If fitting to PVCu profile pre-drill the fixing holes ensuring the drill bit pierces the steel reinforcement. If fitting to timber, drill to a maximum depth of 15mm.

- 4 Place the knocker over the pre-drilled holes and secure into place using the screws provided.
- 5 Position the anvil fixing plate on the door **C**, correctly align with the main knocker to ensure it hits the anvil centrally when operated. The fixing lug, should enable positioning, mark the fixing hole and drill a pilot hole.

Place the anvil over the pre-drilled hole and secure in place.

