




## Balmoral Fixing Plate and Spindle (9B025) Fitting Instructions

### Fitting Instructions

- 1 On the back of the external handle, remove the "Circlip" that holds the spring cassette in place, using a pair of Circlip Pliers.
- 2 Remove the spring cassette from inside the backplate and replace with the external fixing plate.
- 3 Then replace the Circlip.
- 4 Fit the handle onto the door, fitting the round end of the spindle into the external handle and the normal square end of the spindle into the internal handle.
- 5 You will now have a "fixed" outside lever and a movable inside lever.



External Handle



Internal Handle

External Fixing Plate

